

iPad Model numbers in no particular order :

iPad 10.2 2020

<b><u>Models</u></b>	A2428, A2429, A2270,
----------------------	----------------------

iPad 10.2 2019

<b><u>Models</u></b>	A2197, A2200,
----------------------	---------------

iPad Pro 10.5 (2017)

<b><u>Models</u></b>	A1701, A1709,
----------------------	---------------

iPad Air (2019) 10.5

<b><u>Models</u></b>	A2153, A2123, A2152
----------------------	---------------------

iPad Pro 11 (2018)

<b><u>Models</u></b>	A2013, A1934, A1980,
----------------------	----------------------

iPad Pro 11 (2020)

<b><u>Models</u></b>	A2068, a2230, a2228
----------------------	---------------------

iPad 12.9 v3 (2018)

<b><u>Models</u></b>	A2014, A1895, A1876,
----------------------	----------------------

iPad 12.9 v4 (2020)

<b><u>Models</u></b>	A2069, A2232, A2229
----------------------	---------------------

iPad 9.7 (2017)

<b><u>Models</u></b>	A1822, A1823
----------------------	--------------

iPad 9.7 (2018)

<b><u>Models</u></b>	A1893, A1954
----------------------	--------------

iPad Air (2013) = Air 1

<b><u>Models</u></b>	A1474, A1475, A1476
----------------------	---------------------

iPad Air (2014) = Air 2

<b><u>Models</u></b>	A1566, A1567
----------------------	--------------

iPad Air 4 10.9 (2020)

<b><u>Models</u></b>	A2324, A2072
----------------------	--------------